

# MEIKO<sup>®</sup> ACTIVE

## R-GS 2410 GLASS

Concentrated acidic rinse additive for  
glaswashing machines



- provides clean, sparkling results
- ensures fast drying of tableware
- especially for low water hardness
- eliminates the need for additional hand drying
- protects fine glassware



**Instructions for use:**

**MEIKO ACTIVE R-GS 2410 GLASS** is used with a dosing unit. The dosage is determined by water hardness, tableware, type of dishwashing machine etc.

**Recommended dosage**

0,1 – 0,5 ml/l water

**Special information!**

In case of a product switch, a service technician needs to attend. Before the first use of a new product type, always rinse dosing line with clean water to avoid any build-up of crystallisation. Do not mix with any other products!

**Composition and Detergents Regulation information**

Please see safety data sheet.

**Storage conditions**

Store between 0 and 40 °C.

**Safety information**


For professional use only. For further information and safety instructions, see product label and safety data sheet.

**Recommended Detergent**

MEIKO ACTIVE D-GS 1410 GLASS

**Recommended positioning:**

**Materials to rinse**



**Dishwashing conditions**



**pH value (undiluted)**

1	2	3	4	5	6	7	8	9	10	11	12	13	14
---	---	---	---	---	---	---	---	---	----	----	----	----	----



For safety advice please visit:  
<https://m3o.link/uSs>

**Sales unit**  
Jerry can 6L

**Order number**  
9018997



**UFI:** 9FVN-98SY-JG02-9SM6

