

MEIKO[®] ACTIVE

R-US 2000 ECO

Concentrated rinse additive for
dishwashing machines with Ecolabel



- with Nordic Swan Ecolabel
- maximum environmental friendliness
- provides clean, sparkling results
- ensures fast drying of tableware
- eliminates the need for additional hand drying



Instructions for use:

MEIKO ACTIVE R-US 2000 ECO is used with a dosing unit. The dosage is determined by water hardness, tableware, type of dishwashing machine etc.

Recommended dosage

0,2 – 0,5 ml/l water

Special information!

In case of a product switch, a service technician needs to attend. Before the first use of a new product type, always rinse dosing line with clean water to avoid any build-up of crystallisation. Do not mix with any other products! Select low temperature washing cycles on the dishwasher, wash full loads and do not exceed the recommended dosage. This will minimize both energy and water consumption and reduce water pollution. Empty containers should be taken to an approved waste handling site for recycling or disposal. Dispose of in accordance with local, state, and federal regulations.

Composition and Detergents Regulation information

Please see safety data sheet. Packaging and label are made of polyethylene.

Storage conditions

Store between 0 and 40 °C.

Safety information

For professional use only. For further information and safety instructions, see product label and safety data sheet.

Recommended Detergent


MEIKO ACTIVE D-US 1000 ECO



For safety advice please visit:
<https://m3o.link/uSr>

Recommended positioning:


Materials to rinse



Dishwashing conditions



pH value (undiluted)



Sales unit
Jerry can 10L

Order number
9018996

