

MEIKO[®] ACTIVE

M-990 Delimer Heavy Duty

Delimer for commercial dishwashers



- concentrated acidic formulation
- completely strips stubborn oxide layers
- removes lime build-up in dishwashers
- recovers shine on stainless steel surfaces
- keeps heating elements and nozzles in perfect condition



Instructions for use:

Do not dose detergent during deliming process (be sure to switch off the dosing unit.). Drain all wash tanks and fill with fresh water. Dose **MEIKO ACTIVE M-990 Delimer Heavy Duty** according to lime build-up into the wash tank. Start the machine and let it run for 10 - 30 minutes. Drain all wash tanks and rinse with fresh water. Make sure to run machine with fresh water before switching detergent dosage on.

Recommended dosage:

5 – 25 ml/l water

Special information!

Do not use on copper, zinc alloys and porous enamel or marble surfaces. Do not wash crockery during deliming process. Turn off dosing equipment.

Composition and Detergents Regulation information

Please see Safety Data Sheet.

Storage conditions

Store between 0 and 30 °C.

Safety information

Do not mix with any other products! For professional use only. For further information and safety instructions, please see product label and Safety Data Sheet.

pH value (undiluted)

1	2	3	4	5	6	7	8	9	10	11	12	13	14
---	---	---	---	---	---	---	---	---	----	----	----	----	----



For safety advice please visit:
<https://m3o.link/AiY>

Sales unit

Jerry can 6L



UFI: YRX7-DW4A-JG0F-HW74