
MEIKO M-iClean PF

Utensil washer

Installation instructions



For the types in the series: M009DWFL10M1-****

EN

Read before assembling the machine!

Contents

1 NOTICE REGARDING INSTALLATION INSTRUCTIONS 3

1.1 Product identification 3

1.2 Presentation conventions 3

1.2.1 Safety symbols in the instructions 3

2 SAFETY 4

2.1 Safety information 4

3 TRANSPORT 5

3.1 Checking the condition at delivery 5

3.2 Unpacking 6

4 TECHNICAL DATA 6

5 DIMENSIONAL DRAWINGS AND CONNECTION DIMENSIONS 7

6 INSTALLATION 11

6.1 Requirements to the electrical connection 11

6.2 Requirements for the fresh water connection 12

6.3 Requirements for the waste water connection 14

6.4 Requirements for the building ventilation system 14

7 ASSEMBLY 15

7.1 Align machine feet 15

7.2 Install on a plinth 15

7.3 Fit AirConcept (heat recovery) 16

7.4 Connect dosing pipes 20

7.4.1 Connecting suction lances without empty-tank detection 20

7.4.2 Connecting suction lances for empty level indication 21

7.5 Installing the connection for solid substance dosing (optional) 23

7.5.1 Connecting the connection cable of the solid substance dosing system in the machine 26

7.6 Connecting the on-site connection cable of the power optimisation system in the machine in accordance with DIN 18875 27

7.7 Connect external GiO MODULE (optional) 28

7.8 Retrofitting the hold-down grid 33

7.9 Connection 34

7.9.1 Connect waste-water line 34

7.9.2 Connect fresh water line 34

7.9.3 Connect electrically 34

8 COMMISSIONING 34

9 INDEX 35

1 Notice regarding installation instructions

1.1 Product identification

These installation instructions are valid for the product series
MEIKO M-iClean PF-S (M009DWFL1M1-10).

1.2 Presentation conventions

Warnings

⚠ DANGER – indicates an imminently hazardous situation which, if not avoided, will result in serious injury or death.

⚠ WARNING – indicates a potentially hazardous situation which, if not avoided, could result in serious injury or death**.**

⚠ CAUTION – indicates a possible hazardous situation which, if not avoided, could result in minor or moderate injury or damage to property**.**

Notices on use

Note – indicates useful and important information about the product or its use**.**

Notes on using the document:

- A bullet point (•) designates an action step.
- Numerals (1.) designate several action steps that must be executed in the specified sequence.
- Position numbers in the text that refer to position numbers in illustrations are shown in parentheses:
  (1) Position number 1 in the illustration
- The text is always below the illustration and refers to it until a new image follows.

1.2.1 Safety symbols in the instructions

	Read document		Potential equalisation connection
	Caution		Manufacturer

2 Safety

2.1 Safety information

Authorisation for assembly/installation and commissioning

- Assembly may only be performed by a specialist company. Installation may only be performed by electricians/plumbers.
- Commissioning may only be performed by a service technician authorised by MEIKO.

Installation site

- Only furniture that is resistant to condensation should be used in the vicinity of the dishwashing machine.
- Observe the installation conditions (see page 6).

Electrical safety

- The electrical safety of this appliance is only ensured if it is connected to a properly installed protective earth conductor system. It is very important to verify this fundamental safety feature. If in doubt, have the local wiring checked by an electrician. The manufacturer cannot be held liable for damage caused due to the protective earth conductor being missing or disconnected (e.g. electric shock).
- Modifications to electrical systems during installation may only be carried out by a qualified electrician.

Dosing agent

- Take care when handling dosing agents (water softeners/rinsing aids and detergents). They are corrosive substances. Observe the applicable safety regulations! Use safety eyeware and protective gloves. Observe the manufacturer's safety instructions and safety data sheets when handling dosing agents.
- Do not inhale vapours from dosing agents.

General


- Only use the dishwashing machine in its original condition without independent changes and in a technically perfect condition.
- Do not sit or stand on the opened wash chamber door. This could damage the appliance and cause injury.
- Do not place any objects on the dishwashing machine.

3 Transport

⚠ WARNING – danger of injury due to machine tipping

- Only qualified personnel may carry out transport works.
- Please note safety notices on the packaging.
- Always transport the machine on a wooden frame only.
- Wear protective gloves and safety shoes.

The packaging is specifically designed to allow the appliances to be moved safely and securely using a pallet jack. For safe transport, the product is supported by a special square timber frame.



- Execute transport carefully.
- Observe the instructions for safe transport on the packaging.
- Open packaging using a suitable tool.
- Do not unpack the product until it has been transported.

3.1 Checking the condition at delivery

- Check that the delivery is complete immediately after receiving it by comparing it with MEIKO's order confirmation and/or the delivery note.
- If applicable, submit a claim for any missing parts immediately to the freight forwarder and notify MEIKO.
- Check the machine for transportation damage.

Note

If there is any suspicion of transportation damage, the shipping company and MEIKO must be informed immediately in writing. Photograph any damaged parts and send the pictures to MEIKO.

3.2 Unpacking

1. Detach the plastic straps from the cardboard.
2. Remove the cardboard.
3. Remove the anti-slip devices by the feet from the pallet.
4. Have two people carefully push the machine off the pallet so as not to damage the feet.

Removing the protective films

After unpacking the product, remove the protective films from the housing parts and clean the stainless steel surfaces with a suitable detergent.

4 Technical data

Ambient conditions	
Operating temperature	5°C ... 40°C
Relative humidity	< 95%
Storage temperature	5°C ... 40°C
Maximum height of the installation site above sea level	2000 m

Net weight	
M-iClean PF-S	226 kg

GiO MODULE	
Dimensions (W x D x H)	143 x 660 x 600 mm
Connection cable from module to machine	3 m


Noise emission	
Emission sound pressure level at the workplace	≤70 dB (A)

Technical data of the radio module	
Frequency band	2412–2484 MHz
WLAN standard	IEEE 802.11 b/g/n
Bluetooth version	4.2
Max. transmission power	20 dBm

Further data should be taken from the MEIKO dimension sheet.

5 Dimensional drawings and connection dimensions


MEIKO M-iClean PF-S Standard and solid substance dosing option



*	Max. 500 (door open)
**	Max. 2,369 (door open)
A	Entry height
B	Fresh water supply line
C	Drain
D	Electrical supply pipe to the machine
E	Connection for solid detergent detergent dosing unit on site (optional)


MEIKO M-iClean PF-S with lower passing height for low rooms

Note
The bottom door leaf cannot be folded down with this variant.




A	Entry height
B	Fresh water supply line
C	Drain
D	Electrical supply pipe to the machine

MEIKO M-iClean PF-S with AirConcept (heat recovery)



*	Max. 500 (door open)
**	Max. 2,369 (door open)
A	Entry height
B	Fresh water supply line
C	Drain
D	Electrical supply pipe to the machine
F	Separation
G	Installation clearance

MEIKO M-iClean PF-S with GiO MODULE (optional)



*	Max. 500 (door open)
**	Max. 2,369 (door open)
A	Entry height
B	Fresh water supply line
C	Drain
D	Electrical supply pipe to the machine
⚠	GiO MODULE on bracket (W x D x H) 143 x 660 x 600 mm

Country-specific deviations are possible. Binding specifications can be found on the order-specific dimension sheet.

6 Installation

6.1 Requirements to the electrical connection

Electrical connection must be carried out in accordance with the locally applicable regulations (e.g. HD 60364-1/IEC 60364-1/VDE 0100-100) so the machine can be connected to the mains supply in accordance with the installer's regulations. However, national installer's regulations may differ. The machine and accessory appliances are intended for permanent connection to the on-site power supply and the on-site protective equipotential bonding and have been tested accordingly before being brought to market.

Fuse protection


- Set up the machine according to the local conditions and according to the rated current (see rating plate) as a separately fused circuit (final circuit). Take note of the available connection variants.
- The requirements for limiting voltage changes, fluctuations and flicker in accordance with IEC 61000-3-11 are fulfilled for this machine if the network has a current-carrying capacity of ≥ 100 A.

Main switch/mains connection cable

- Install a main switch with all-pole disconnection from the mains in accordance with the installer's regulations in the permanently installed on-site installation.
- The main switch must be easily accessible for the operating personnel.
- The contact opening width must correspond to overvoltage category III in each pole.
- Mains power cables, unless part of the standard product scope of supply, must be oil-resistant, sheathed, flexible cables no lighter than a normal polychloroprene-sheathed cable (or other equivalent synthetic elastomer) with the marking 60245 IEC 57.
- Mains connection cables may only be replaced by persons trained by MEIKO.

Electrical safety

- The electrical safety of this machine is only ensured if it is connected to a properly installed protective conductor system. It is very important to verify this fundamental safety feature. If in doubt, have the building wiring checked by an electrician.
- Carry out the protective measures as well as the connection of the equipotential bonding in accordance with the regulations of the local power supply companies as well as the locally applicable regulations.
- As an alternative to equipotential bonding, the operator can, acting on its own responsibility, use a mains-side residual current device (RCM or RCD) for personal protection. A type “A” according to IEC 60755 is sufficient.

Electrical connection	
Voltage	See rating plate
Total connected load	
Fuse protection	
Equipotential bonding	 Located in the middle behind the lower front panel and on the rear of the GiO MODULE (optional).
Mains connection terminal strip	5-pin (with neutral conductor) 4-pin (without neutral conductor)
Special national conditions	USA/Canada: The machine must be installed in accordance with local regulations. In the absence of any such regulations, install the machine in accordance with the applicable requirements in the National Electrical Code, NFPA 70, Canadian Electrical Code (CEC), Part 1, CSA C22.1 and the Standard for Ventilation Control and Fire Protection of Commercial Cooking Operations, NFPA 96. Australia/New Zealand: Carry out all work in accordance with AS/NZS 3000!

6.2 Requirements for the fresh water connection

- Fresh water connections must comply with the locally applicable regulations (e.g. DIN EN 1717). Install a shut-off device on site in each fresh water supply line; the device must be easily accessible for the operating personnel. This dishwashing machine is installed as a fully functional unit and only needs to be connected to the local power and water supply.
- Only connect the dishwashing machine using suitable hoses and seals. Hoses may only be used if in an intact condition!
- When replacing an old machine with a new one, make sure that the existing feed hose is exchanged for the new feed hose supplied with the machine.
- The hoses have a ¾ inch thread for connecting to the on-site shut-off valves.

Fresh water connection	
Water quality	From a microbiological perspective, the fresh water must be of drinking water quality. This also applies to treated water.
Air gap	Type AB according to DIN EN 1717 or DIN EN 61770 with pressure booster pump after air gap
Equipment	Solenoid valve/leakage detector switch
Flow rate	Min. 8.0 l/min
Minimum flow pressure With GiO MODULE	60 kPa / 0.6 bar before the solenoid valve 100 kPa/1 bar
Maximum pressure	500 kPa/5.0 bar (1000 kPa in DK, SV, NO, FI)
Shut-off valve and fine filter to be provided on site	≤ 25 µm
Max. feed water temperature With GiO MODULE With exhaust air heat recovery With VZ20 DELTA Soft water softener	60°C 35°C 20°C 50°C
Special national conditions	In the case of SVGW (Switzerland) and other countries, a type EA safety device is also required upstream of the connection hose. Higher maximum pressure in Denmark, Sweden, Norway, Finland (see above) For Australia and New Zealand only: All work carried out must be in accordance with AS/NZS 3500.1!

Fresh water limit values when operating a reverse osmosis module	
Designation	**Value**
Conductivity	70–1000 µS/cm
Water hardness	0–28 dH
Feed water temperature	Min. 1°C to max. 35°C (cold water connection)
Minimum flow pressure	100 kPa (1 bar)
Maximum pressure	500 kPa (5 bar)
Free from particles	> 10 µm
Iron	< 0.1 mg/l
Manganese	< 0.04 mg/l
Chlorine (free chlorine)	< 0.1 mg/l (standard membrane)
Chlorine (free chlorine)	≥ 0.1 to ≤ 2.0 mg/l (more chlorine-resistant membrane)
Potassium permanganate	< 10 mg/l
Silicic acid	< 10 mg/l

6.3 Requirements for the waste water connection

- Waste water connections must comply with DIN EN 1256 and the locally applicable regulations.

Waste water connection	
Drain pump present?	Yes
Grease separator	Observe local regulations
Maximum drain height above finished floor	With GiO MODULE: 650 mm Without GiO MODULE: 700 mm
Connecting hose extending from the machine	2 m
Special national conditions	Australia: The drain hose must be connected so that it is waterproof with a drain fitting in accordance with AS 1589 AS 2887 and a sanitary waste water pipe or sanitary waste water fitting in accordance with AS/NZS 1260

6.4 Requirements for the building ventilation system

- The building ventilation system must comply with the locally applicable regulations (e.g. EN 16282), and must always be watertight and corrosion-resistant.
- The exhaust air may contain small amounts of aerosols, therefore discharge exhaust air through suitable exhaust air zones or exhaust air hoods.
- If the exhaust air is discharged into the surrounding room, adjust the discharged volumetric air flow.


7 Assembly

7.1 Align machine feet

1. Place the machine at its destination using the pallet jack.



2. Relieve the pressure on the foot and adjust it to the desired height using a suitable spanner. Do not use pliers!




3. To adjust the foot, use a short spanner with a width across flats of 50.



4. Check the level of the machine using a spirit level.


7.2 Install on a plinth

1. Lift the machine with the pallet jack and unscrew the machine feet.




2. Guide the lines with cable protection through the opening on the desired side.
3. Place the machine on the plinth using the pallet jack.
4. To align the machine, screw M10 screws from the inside into the nuts of the machine feet.
5. For fine alignment, if necessary, shim on the front side.


7.3 Fit AirConcept (heat recovery)




1. Place the heat exchanger unit on the dishwashing machine and insert the threaded bolts on the dishwashing machine through the holes in the heat exchanger unit. Position the connections for the hoses on the left-hand side.



2. Secure the heat exchanger unit with 4 M5 safety nuts.



3. Attach the bracket on the left side. Ensure that the bracket is correctly fitted.




4. Place the fan unit on the heat exchanger unit and guide the threaded bolts of the fan unit through the holes in the heat exchanger unit.




5. Secure the fan unit with 4 M5 safety nuts.




6. Slide the four clips onto the holes on the sides of the fan unit.



7. Fit the electrical box on the right side and insert the threaded bolts through the holes in the electrical box.



8. Secure the electrical box with 2 M5 safety nuts.




9. Fit the solenoid valve on the back and pass the threaded bolts through the holes in the bracket.



10. Secure the solenoid valve with 2 M5 safety nuts.



11. Connect the hoses and tighten them by hand. Secure the upper hose on the front with a spring band clamp.
When fitting the hoses, pay attention to the colour markings.






12.Lay the cables on the machine according to the cable length and secure them with the enclosed clamps.





13.Attach the protective conductor on the side with connection plan Z.




14.Slide in the heat exchanger unit casing from the front and hook it onto the sides.



15.Secure the heat exchanger unit casing on the front with 2 self-tapping screws.






16. Slide the 7 clips onto the holes in the casing for the fan unit.




17. Push in the fan unit casing from the front. Secure the casing with 4 self-tapping screws per side and 2 self-tapping screws on the front.





18. Hook in the rear panel at the top and secure it with 8 self-tapping screws.




19. Put on the cover and secure it with 6 self-tapping screws.

7.4 Connect dosing pipes

⚠ WARNING – Risk of injury from contact with chemicals

- Observe the safety data sheets and dosing recommendations of the chemical manufacturers.
- Use eye protection.
- Wear protective gloves.
- Do not mix different chemical products.

7.4.1 Connecting suction lances without empty-tank detection



The connections for detergent (red), rinse aid (blue) and the third dosing agent (optional) are located in the middle at the bottom of the back of the machine (1).

1. Connect the hoses with the suction lances according to the colours and secure them with a collar clamp.



2. Punch a hole in the centre of each of the detergent and rinse aid canister covers.
   Note: The hole must be large enough for pressure equalisation to take place.



3. Guide the suction lances into the canisters and through the hole in the canister cover. Screw on the canister covers tightly.




4. Connect the transparent hose to the suction lance in the white canister for detergent. To secure in place, squeeze the clamp at the connection and release it at the correct position.



5. Connect the blue hose to the suction lance in the blue rinse aid canister. Tighten the clamp on the connection.
6. Place the canisters for detergent and rinse aid according to the environment.

7.4.2 Connecting suction lances for empty level indication


Connecting suction lance dosing hoses and cables



The connections for rinse aid (blue) and detergent (red) are located in the middle at the bottom of the back of the machine (1).




1. Attach the labels for rinse aid (blue) and detergent (red) to the hose and cable of the suction lances using cable ties. The suction lances are identical in construction. The labels are used to distinguish the canisters.





2. Push the rinse aid and detergent suction lance hoses (blue or red label respectively) as far as they will go onto the correspondingly labelled connection nozzles. Secure with the hose clamps.



3. Insert the rinse aid and detergent suction lance plugs (blue or red label respectively) into the corresponding colour-coded connection sockets.
4. Secure the cables of the two suction lances to the clip provided with a cable tie.


Note

The rubber bung on the suction lance is suitable for canister openings with a diameter of between 30 mm and 37 mm. Larger canister openings require the installation of a canister lid:

Fitting the suction lance on the canister



1. Drill a 32 mm diameter hole in the centre of the canister lid using a step drill or peeler drill bit.



2. Press the rubber bung on the suction lance into the hole in the canister lid.
3. Insert the suction lance into the canister opening until it the bottom of the canister, hold it at the top and screw on the canister lid.

Note

When using canisters > 5 l, the authorised MEIKO service technician must adjust the machine settings during commissioning.


7.5 Installing the connection for solid substance dosing (optional)

Material: Installation kit for solid substance dosing (9842052)


Note

- The dosing point can be attached on the left or right side of the machine. The attachment for the right side is shown below as an example. When mounted on the left side, the representations are to be understood as mirror images.
- Where machines have a GiO MODULE mounted on the side, the dosing point must be installed on the side opposite the side with the GiO MODULE.


Position of the hole in the side wall



Position of the hole in the wash chamber




Position of the electrode to measure conductivity



Install dosing point

1. Select the side for the dosing point.




3. Place the rectangular cut-out on the side wall. To easily separate the cut-out, drill a Ø 8 mm hole in each corner.

2. Remove the side wall.



4. Drill the hole for the dosing connection on the wash chamber.



5. Fit the dosing connection with O-ring, washer and hexagon nuts on the wash chamber.
6. Install the side wall.



7. Push the cover plate with grommet over the dosing connection and align it. Mark the position of the 2 threaded bolts for securing the cover plate.






8. Weld on the 2 threaded bolts (M5x8).

9. Mount the cover plate with washer and cap nut (M5). Attach the 90° hose connection.

10. Remove the tank cover sieve and the filter.

11. Drill the hole for the measuring electrode at the tank bottom. The hole diameter may change depending on the conductivity probe to be installed.






12. If the solid dosage is not used, the hole for the dosing connection in the wash chamber must be closed with the sealing plug, the O-ring and the hexagon nut. The grommet of the cover plate must be replaced with the sealing plug.


7.5.1 Connecting the connection cable of the solid substance dosing system in the machine

Note


Use only multi-wired power supply cables with at least 1.5 mm² 3G and a rated voltage of at least U0/U = 300/500 V. Good mechanical and chemical resistance is a prerequisite. The cable must be resistant to temperatures up to at least +80°C.



1. Insert the cable at the rear of the machine at the cut-outs provided. Lay between the wash pump and tank in the direction of the electrical box as shown and fix in place. It is permitted to lay the cables with the existing load circuit (230 V/400 V).



2. Guide through the lower opening into the electrical box.





3. Lay and fix the cable in the electrical box to the connection points (terminals and relays). Refer to the wiring diagram for the pin assignment.

7.6 Connecting the on-site connection cable of the power optimisation system in the machine in accordance with DIN 18875


Note

Use only multi-wired power supply cables with at least 1.5 mm² 3G and a rated voltage of at least U_0/U = 300/500 V. Good mechanical and chemical resistance is a prerequisite. The cable must be resistant to temperatures up to at least +80°C.






1. Insert the cable at the rear of the machine at the cut-outs provided. Lay along the tank in the direction of the electrical box as shown. There are already 24 V control lines running here, to which the cable can be fixed.



2. Feed the cable through the upper opening (for 24 V) into the electrical box.



3. Route the cable in the electrical box to the terminals and connect. Refer to the wiring diagram for the pin assignment.


7.7 Connect external GiO MODULE (optional)

Note

The GiO MODULE can be attached to a console on the dishwasher or connected as a free-standing unit.


Mounting on retaining plate

1. Loosen the 6 screws of the cover of the GiO MODULE and carefully remove the cover.
   The protective conductor is mounted on the inside of the cover. Make sure that the cable is not damaged.





2. Guide the fresh water supply line (4) and the transparent fabric hoses for permeate recirculation (1), permeate (3) and concentrate (2) through the side opening in the casing.




3. Connect the transparent fabric hoses for permeate recirculation (1), permeate (3) and concentrate (2) to the connections according to the colour coding and secure them with circlips.



4. Secure the fresh water supply line to the pre-filter with a spring band clamp and connect the bend plug connection.



5. Fit the circlips.



6. Insert the two plugs of the machine connection cable into the sockets provided, lock and secure with cable ties.




7. Connect the equipotential bonding.




8. Tighten the hoses from the outside and attach the cover.




9. Break out the holes in the base drip tray for the reinforcement profile (see picture).





10. Insert the reinforcement profile from the inside into the base drip tray and insert the welded hexagon screws through the holes in the base drip tray.



11. Position the plinth and insert the hexagon screws through the holes in the plinth.




12. Screw the plinth with 2 washers and M6 self-locking nuts.

13. Attach the side panel of the machine. Retrofitting is not possible!



14. Place the GiO MODULE on the plinth and align it.



15. Position the holding bracket. Distance from the top edge of the GiO MODULE: 70 mm.

16. Drill out the holding bracket on the side wall.
17. Screw the holding bracket with M5 hexagon screws, washers and self-locking nuts.



18. Insert the filter element and screw in the pre-filter hand-tight.




19. Hook in the pre-filter casing and push it down.

20. Screw the casing together.


Freestanding assembly

1. Loosen the 6 screws of the cover of the GiO MODULE and carefully remove the cover.
   The protective conductor is mounted on the inside of the cover. Make sure that the cable is not damaged.





2. Guide the fresh water supply line (4) and the transparent fabric hoses for permeate recirculation (1), permeate (3) and concentrate (2) through the side opening in the casing.



3. Connect the transparent fabric hoses for permeate recirculation (1), permeate (3) and concentrate (2) to the connections according to the colour coding and secure them with circlips.



4. Secure the fresh water supply line to the pre-filter with a spring band clamp and connect the bend plug connection.



5. Insert the circlips




6. Connect the electrical connections.




7. Connect the equipotential bonding.



8. Place the GiO MODULE on the foot and insert the welded hexagon screws on the foot into the holes on the underside of the GiO MODULE.



9. Place the perforated rail and the 2 washers on the hexagon screws.




10. Screw the foot with 2 M6 safety nuts.



11. Tighten the hoses from the outside and attach the cover.
12. Insert the filter element and screw in the pre-filter hand-tight.
13. Hook in the pre-filter casing and push it down.
14. Screw the casing together.

7.8 Retrofitting the hold-down grid

Sequence of fixing sets (example shows left-hand side of rack)



1 Mounting plate for outside of rack
2 Rack position
3 Mounting plate for inside of rack
4 Spring
5 Hold-down grid position
6 Fixing material

Mounting




1. Place the spring on the axle of the hold-down grid as shown and hook the right-hand leg of the spring onto the hold-down grid from below.
2. Insert the left-hand leg of the spring into the smallest hole on the mounting plate for the inside of the rack.



3. Rotate the mounting plate for the inside of the rack downwards and insert the axle of the hold-down grid into the top left hole.
4. Position the mounting plate on the rack as shown.



5. Fit the mounting plate for the outside of the rack.



6. Fix the two mounting plates in place.



7. Proceed in mirror image on the opposite side.

7.9 Connection

7.9.1 Connect waste-water line

1. Connect the drain hose to the on-site wastewater connection using a suitable drain fitting.

7.9.2 Connect fresh water line

Recommendation: Flush the on-site piping/shut-off valves and hoses before connecting the dishwashing machine. To do this, connect the hoses to the shut-off valves, open the valves carefully and collect the water in a bucket.

1. Check the hoses for damage.
2. Connect to the on-site shut-off valves.
3. Slowly open the shut-off valve and check that it is watertight. In the event of leaks, rectify the cause and check again that it is watertight.

7.9.3 Connect electrically

⚠ WARNING – Danger to life from electric shock

- Work on the electrical system may only be carried out by a qualified electrician.
- Disconnect the machine from the power supply before working on the electrical system. To do this, turn the local mains switch to OFF and ensure that it cannot be switched back on again.

Connect the connection cable already connected to the dishwashing machine to the on-site junction box.

8 Commissioning

After the machine has been connected electrically and to the water supply, request a MEIKO authorised service technician for handover.

This person must check the entire installation and carry out commissioning. Subsequently, the operating personnel is instructed on the basis of the handover protocol. The machine will then be signed over to your authorised representative.

9 Index

A

Assembly 15
- Align machine feet 15
- Connect dosing pipes 20
- Connect external GiO MODULE 28
- Fit AirConcept (heat recovery) 16
- Install on a plinth 15

C

Checking the condition at delivery 5
Commissioning 34
Connection 34
- electrical 34
- fresh water line 34
- waste-water line 34

Connection dimensions 7

D

Designation of machine type 3
Dimensional drawings 7
- M-iClean PF-S Standard and solid substance dosing option 7
- M-iClean PF-S with AirConcept (heat recovery) 9
- M-iClean PF-S with GiO MODULE (optional) 10
- M-iClean PF-S with lower passing height 8

I

Installation 11
- Solid substance dosing 23

N

notes 3
Notices on use 3

P

Presentation conventions 3

R

Requirements for the building ventilation system 14
Requirements for the fresh water connection 12
Requirements for the waste water connection ... 14
Requirements to the electrical connection 11
Retrofitting the empty indicator 21
Retrofitting the hold-down grid 33

S

Safety 4
Safety information 4
Safety symbols in the instructions 3

T

Technical data 6

U

Unpacking 6

The clean solution

MEIKO Maschinenbau GmbH & Co. KG
Englerstraße 3
77652 Offenburg
Germany
www.meiko-global.com
info@meiko-global.com

9022337 / Valid from: 2022-04 / Update: 2026-06